

Elite Upgrade Kit

3A3084A

EN

For converting a standard Reactor® 2 hydraulic proportioner to an elite Reactor 2. For professional use only.

Kit No. 17F838

Important Safety Instructions


Read all warnings and instructions in this manual and in Reactor 2 proportioner manual, fluid inlet sensor manual, and Graco InSite™ manual. Save all instructions.

Parts

Ref.	Part	Description	Qty.
1	24T280	KIT, Graco Insite	1
2	17F837	KIT, fluid inlet sensor	1
3	17F406	LABEL, Elite	1

Related Manuals

Manual	Description
334945	Reactor 2 Hydraulic Proportioner Operation
334946	Reactor 2 Hydraulic Proportioner Repair
3A3009	Fluid Inlet Sensor Kit
333276	Graco InSite Installation Kit



ti26465a

Graco Information

For the latest information about Graco products, visit www.graco.com.

For patent information, see www.graco.com/patents.

TO PLACE AN ORDER, contact your Graco distributor or call to identify the nearest distributor.
Phone: 612-623-6921 or Toll Free: 1-800-328-0211 Fax: 612-378-3505

*All written and visual data contained in this document reflects the latest product information available at the time of publication.
Graco reserves the right to make changes at any time without notice.*

Original instructions. This manual contains English. MM 3A3084

Graco Headquarters: Minneapolis

International Offices: Belgium, China, Japan, Korea

GRACO INC. AND SUBSIDIARIES • P.O. BOX 1441 • MINNEAPOLIS MN 55440-1441 • USA
Copyright 2015, Graco Inc. All Graco manufacturing locations are registered to ISO 9001.

www.graco.com

Revision A, May 2015